



Basic Instructions for Mixmaster Power Cord Replacement.

Release the mixer head off of the stand by pushing down the lever at the top of the stand.

The cord attaches on the under side. There is a small plate with a screw bearing the model number. Remove the screw.



With a small screwdriver gently pry up on the hole where the screw was. It will raise up the front of the plate.

Pull up and forward on the plate to remove it. Remove the rubber insulator pad below it. Cut the old cord off close to the rear of the mixer. Pull the remaining cord through to the "wire compartment".

The wires are soldered on. Raise them up as far as they will allow you to. With a soldering iron heat them up and with a pair of needle nose pliers, separate the power cord wires from the field coil wires. Pull the small piece of cord out. After cutting to length and stripping the wires, push the new cord through the hole in the rear of the mixer

And solder them back on to the field coli wires.

Tuck the connections down into the slots and replace the rubber insulating pad. Insert the plate in to their slots and push down firmly on the plate so that the screw can be started. Tighten the screw until the plate is seated.

These instructions are for guidance only!

We recommend that a licensed electrician perform this task and accept no liability for any harm to your person or the mixer.